



ITEM# WRL-RACING

powered by 

Congratulations on your purchase of the RC Racing Link. The RC Racing Link is designed to interface with all popular brands of radio control systems as a PC based USB game controller. This allows you to practice racing R/C models with most types of racing simulator software. It is also equipped with servo plugs that provide easy installation to your R/C vehicle receiver. This RC racing link is compatible with any R/C receiver with 2 channel Futaba type inputs.

Please read the entire manual before proceeding. Before installation, be sure your radio system uses center red or positive receiver/servo connections.

Features:

- Radio control system to PC USB game controller interface.
- Easy USB Plug and Play operation with Windows 98, ME, 2000, XP & Windows 7.
- Reads up to 2 Analog Channels from the receiver with auto self calibration.
- No Software Drivers required.
- LED indicator status.

Package Contents:

- RC Racing Link unit
- User Instruction Manual

Hardware Installation

1. Plug the RC Racing Link servo plug(s) into your RC receiver servo port(s).
2. Plug in the USB connection of the RC Racing Link to an available USB port on your PC.
3. Windows should automatically detect the RC Racing Link, and the LED status indicator should blink on and off. If not, try plugging the device to a different USB port. (for Windows 98 SE, be sure to install the Windows CD-ROM if requested)
4. Open the Windows game controller applet by selecting start->Settings->Control Panel->Game Controllers.
5. Select the "RC Racing Link" controller in the game controller's applet and click on properties.
6. Finally, move both of your RC transmitter axes to its full extents. This will allow the RC Racing Link to self calibrate to all your channels. All axes should respond to your RC transmitter accordingly.

Troubleshooting FAQ

Q: Why doesn't the RC Racing Link work under Windows 98 SE?

A: Windows 98 doesn't install the drivers by default for USB devices. It requires additional files from the Windows CD-ROM, if you fail to install these files, Windows will not recognize the controller.

Please insert your Windows 98 SE CD-ROM when installing the RC Racing Link.

Q: The RC Racing Link does not calibrate properly?

A: Disconnect the Racing Link USB connection and reconnect it. Move all your RC transmitter axes to its limit for recalibration.

Disclaimer and Limitation of Liability

Western Robotics Ltd. shall have no liability or responsibility to the user or any other party or entity with respect to any liability, injuries, loss or damage, cause or alleged to be caused, directly or indirectly, for equipment sold, furnished or supplied by Western Robotics Ltd.

Notwithstanding the above limitations, Western Robotics Ltd. is not liable for damages incurred by customers or to the customers. Western Robotics Ltd. is not liable for the particular equipment involved.

Neither Western Robotics Ltd. nor this document makes any expressed or implied warranty, including, but not limited to the implied warranties of merchantability, quality or fitness for a particular purpose.

Specifications are subject to change without notice.

Limited Warranty (North America Only)

The RC Racing Link is guaranteed to be free from defects in material and workmanship for a period of 90 days from the date of purchase accompanied by the proof of purchase or invoice. Warranty does not cover damage due to improper use or incorrect installation.

During the 90 day warranty period, if the product shows defects caused by abuse, accident or misuse, it will be repaired or replaced upon Western Robotics Ltd. sole discretion, at a service charge not greater than 40% of the current retail list price. Please ensure to include your contact information before any repair(s) or replacement(s) can be conducted. Under no circumstances or condition will the purchaser be entitled to consequential or incidental damages. In no case shall our liability exceed the product's original cost. We reserve the right to modify warranty provision without notice. Because Western Robotics Ltd. has no control over connection and use of this product, no liability may be assumed nor will be accepted for damage resulting from the use of this product, user accepts all resulting liability. If you attempt to disassemble, modify or repair this unit yourself, it may void the warranty.

For warranty service on Western Robotics product(s) in, out or off warranty period, please send the defective unit(s) along with the proof of purchase and a description of the problem, postage paid, to the given address below.

Customer Service
Western Robotics Ltd.
215-12837 76th Avenue
Surrey, BC
V3W 2V3 Canada
info@western-robotics.com